



**FOUNDATIONLESS REQUIREMENTS:**

- Centered on a square foot area that is free from cracks, seams, and walls.
- Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
- Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
- Concrete must contain wire mesh reinforcement.

CREATED BY: HOOSIER CRANE SERVICE

**GORBEL**

600 FISHERS RUN  
P.O. BOX 593  
FISHERS, NY 14453-0593

MODEL NO.: WSJ360-NP6-150-8-8

CAPACITY: 150  
SPAN: 8'-0"  
H.U.B.: 8'-0"

QUANTITY: 1  
SHIPPING WT.: 390

DRAWN: brea11

DATE: DEC 29, 2014

C.O.#: test

P/N: test.1A

150 LB CAPACITY

**NOTES:**

- 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.
- 2) DO NOT SCALE FROM THIS DRAWING.