



FOUNDATIONLESS REQUIREMENTS:

- Centered on a square foot area that is free from cracks, seams, and walls.
- Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
- Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
- Concrete must contain wire mesh reinforcement.

50 LB CAPACITY

CREATED BY: HOOSIER CRANE SERVICE

GORBEL

600 FISHERS RUN
P.O. BOX 593

FISHERS, NY 14453-0593

MODEL NO.: TSJ50-FS-50-10-8

CAPACITY: 50

SPAN: 8'-0"

H.U.B.: 10.00 FT.

QUANTITY: 1

SHIPPING WT.: 165 LBS

DRAWN: breall

DATE: DEC 29, 2014

C.O.#: test

P/N: test.1A

NOTES:

- 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.
- 2) DO NOT SCALE FROM THIS DRAWING.