



- FOUNDATIONLESS REQUIREMENTS:**
- Centered on a square foot area that is free from cracks, seams, and walls.
 - Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
 - Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
 - Concrete must contain wire mesh reinforcement.

50 LB CAPACITY

CREATED BY: HOOSIER CRANE SERVICE

GORBEL
 600 FISHERS RUN
 P.O. BOX 593
 FISHERS, NY 14453-0593

MODEL NO.: TSJ50-FS-50-8-6

CAPACITY: 50
 SPAN: 6'-0"
 H.U.B.: 8.00 FT.

QUANTITY: 1

SHIPPING WT.: 140 LBS

DRAWN: breal

DATE: DEC 29, 2014

C.O.#: test

P/N: test.1A

- NOTES:
- 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.
 - 2) DO NOT SCALE FROM THIS DRAWING.