



- FOUNDATIONLESS REQUIREMENTS:**
- Centered on a square foot area that is free from cracks, seams, and walls.
 - Reinforced Concrete with Pressure of 3000 psi and Soil Pressure of 2500 psf.
 - Chemical anchor bolts to withstand a minimum of 3,470 lbs. of pull out force.
 - Concrete must contain wire mesh reinforcement.

150 LB CAPACITY

NOTES:
 1) JIB CRANE FOUNDATION REQUIREMENTS ARE BASED ON A SOIL PRESSURE OF 2500 LBS PER SQUARE FOOT. CONCRETE RECOMMENDED FOR JIB CRANE FOUNDATION IS 3000 LBS PER SQUARE INCH OF COMPRESSIVE FORCE.
 2) DO NOT SCALE FROM THIS DRAWING.

CREATED BY: HOOSIER CRANE SERVICE

GORBEL

600 FISHERS RUN
 P.O. BOX 593
 FISHERS, NY 14453-0593

MODEL NO.: TSJ150-FS-150-10-6

CAPACITY: 150
 SPAN: 6'-0"
 H.U.B.: 10.00 FT.

QUANTITY: 1

SHIPPING WT.: 358 LBS

DRAWN: breadl

DATE: DEC 29, 2014

C.O.#: test

P/N: test.1A